




ASSEMBLE YOUR AIR FRYER



1. Place the air fryer on a flat, stable, heat resistant surface close to an electrical outlet.
Warning: Do NOT place the air fryer underneath cabinets.




2. Insert the crisper baking tray with or without the separator.



3. Insert the basket into the air fryer and lock into place.


**1 YEAR
LIMITED WARRANTY**

GETTING TO KNOW YOUR 11-QT MULTIFUNCTIONAL AIR FRYER



Product may vary slightly from illustration.

CONTROL PANEL



- | | |
|------------------------------------|--------------------------|
| 1 AIR FRY | 10 TEMP CONTROL (+ OR -) |
| 2 ROAST | 11 START OR PAUSE |
| 3 BROIL | 12 LEFT BASKET CONTROL |
| 4 BAKE | 13 SYNC FOOD FINISH |
| 5 DUAL DIGITAL TEMP & TIME DISPLAY | 14 SWITCH |
| 6 REHEAT | 15 DUAL COOK |
| 7 DEHYDRATE | 16 RIGHT BASKET CONTROL |
| 8 KEEP WARM | 17 ON/OFF CONTROL |
| 9 FRENCH FRIES | 18 TIME CONTROL (+ OR -) |

Sur la table

SINGLE OR DOUBLE BASKET AIR FRYER

11 QUART/10.5 LITER

QUICK START GUIDE



Scan Here to
Learn More!

www.mcappliances.us

START COOKING

IMPORTANT: Maximum food capacity for air fryer basket is 11 quarts of food per basket.

Cook using the full basket:

1. Plug the air fryer cord into an electrical outlet. The ON/OFF control will light up in white.
2. Place food on the crisper baking tray in the air fry basket without the separator.
 - a. **WARNING:** Do NOT Overfill. To ensure proper cooking and air circulation, NEVER fill any Air Fryer Basket more than 2/3 full.
 - b. **NOTE:** When air frying fresh vegetables, it is not recommended to add more than 2 to 3 cups of food to the Air Fryer Basket.
3. Insert the basket into the air fryer and lock into place.
4. Press the ON/OFF control. The control panel will illuminate.
5. Press Switch.
 - a. **NOTE:** The L, R, Sync, and Dual Cook buttons will turn off. Sync buttons will turn off.
6. Press the desired cooking function. The default cooking time and temperature with flash.
7. If necessary, adjust the cooking time and temperature using the + or – buttons.
 - a. **NOTE:** In the Dehydrate Setting, time is adjustable in 1 hour increments.
8. Press the start/pause button to initiate the cooking process.
 - a. **NOTE:** To pause the cooking process, press the start/pause button. To resume the cooking process, press the start/pause button.
 - b. **NOTE:** Two-thirds through the cooking process, the air fryer will beep and the display will show SHK, reminding you it's time to shake or flip your food for even cooking.
9. When the remaining time reaches 00:00, the display will show a countdown of 20 seconds, the air fryer will beep 5 times and turn off.

Cook using both baskets:

1. Plug the air fryer cord into an electrical outlet. The ON/OFF control will light up in white.
2. Place food on the crisper baking tray in the air fry basket with the separator.
 - a. **WARNING:** Do NOT Overfill. To ensure proper cooking and air circulation, NEVER fill any Air Fryer Basket more than 2/3 full.
 - b. **NOTE:** When air frying fresh vegetables, it is not recommended to add more than 2 to 3 cups of food to the Air Fryer Basket.
3. Insert the basket into the air fryer and lock into place.
4. Press the ON/OFF control. The control panel will illuminate.
5. Press the L button to set up the cooking process for the food on the left basket.
6. Press the desired cooking function. The default cooking time and temperature with flash.
7. If necessary, adjust the cooking time and temperature using the + or – buttons.
8. Press the R button to set up the cooking process for the food on the right basket.
9. Press the desired cooking function. The default cooking time and temperature with flash.

10. If necessary, adjust the cooking time and temperature using the + or – buttons.
 - a. **NOTE:** Press the Sync button to synchronize the cooking time in each basket so both dishes finish cooking at the same time.
11. Press the start/pause button to initiate the cooking process.
 - a. **NOTE:** To pause the cooking process, press the start/pause button. To resume the cooking process, press the start pause button.
 - b. **NOTE:** Two-thirds through the cooking process, the air fryer will beep, and the display will show SHK, reminding you it's time to shake or flip your food for even cooking.
12. When the remaining Time reaches 00:00, the display will show a countdown of 20 seconds, the air fryer will beep 5 times and turn off.

Cook using only one basket:

1. Plug the air fryer cord into an electrical outlet. The ON/OFF control will light up in white.
2. Place food on the crisper baking tray in the air fry basket with the separator.
 - a. **WARNING:** Do NOT Overfill. To ensure proper cooking and air circulation, NEVER fill any Air Fryer Basket more than 2/3 full.
 - b. **NOTE:** When air frying fresh vegetables, it is not recommended to add more than 2 to 3 cups of food to the Air Fryer Basket.
3. Insert the basket into the air fryer and lock into place.
4. Press the ON/OFF control. The control panel will illuminate.
5. Press the L or R button to set up the cooking process for the food in the desired basket.
6. Press the desired cooking function. The default cooking time and temperature with flash.
7. If necessary, adjust the cooking time and temperature using the + or – buttons.
8. Press the start/pause button to initiate the cooking process.
 - a. **NOTE:** To pause the cooking process, press the start/pause button. To resume the cooking process, press the start pause button.
 - b. **NOTE:** Two-thirds through the cooking process, the air fryer will beep, and the display will show SHK, reminding you it's time to shake or flip your food for even cooking.
9. When the remaining Time reaches 00:00, the display will show a countdown of 20 seconds, the air fryer will beep 5 times and turn off.

SPECIAL FUNCTIONS

Sync Food Finish:

Sync Finish feature independently adjusts temperature and cooking time in each basket to allow two different dishes to finish cooking at the same time. To set up, simply program both sides, press sync and start/pause.

The cooking time will appear on both sides and the countdown will begin on the side with more time. When the remaining time on both sides are even, the countdown will proceed on both sides.

NOTE: Once cooking has started, Sync function will not be operable.

Dual Cook:

Dual Cook function allows you to transfer settings from one basket to the other at the touch of a button. To set up, simply program one of the baskets with the desired cooking function, time and temperature. Then, press dual cook to copy that recipe on to the other basket. Finally, press the start/pause button to initiate the cooking process.

Shake:

Shake reminder let's you know when it's time to shake your food. You don't have to do anything to set this function up. Two-thirds through the cooking function, the display will show SHK reminding you to shake or flip your food for even cooking.

PRE-PROGRAMMED COOKING SELECTIONS

MENU	DEFAULT TEMP (°F)	DEFAULT TIME	DUAL COOK TIME	TEMP RANGE (°F)	TIME RANGE
Air Fryer	400	20 mins	23 mins	170 - 400	1 – 60 mins
Roast	400	35 mins	37 mins	350 - 400	1 – 60 mins
Broil	400	10 mins	13 mins	400	1 – 30 mins
Bake	350	16 mins	19 mins	170 - 400	1 – 60 mins
Reheat	250	6 mins	9 mins	170 - 400	1 – 60 mins
Dehydrate	130	8 hours	8 hours	90 - 170	1 hr - 24 hrs
Keep Warm	170	60 mins	60 mins	150 - 200	1 – 60 mins
French Fries	400	20 mins	30 mins	170 - 400	1 – 60 mins